



4960 SW 29th Way, Ft. Lauderdale, FL 33312
Phone: 305-345-9444

Billet Right Side Engine Wedge Bracket Installation Guide

READ COMPLETELY BEFORE BEGINNING

This bracket is specifically designed to allow the mounting of a right side CycleOps USA engine wedge on Victory bikes not already equipped with a right side mounting point. It is not designed for use with the OEM 'Cheese Wedges' or other aftermarket offerings, (although with some slight modification by the end user it could likely be used).

Place the bracket to the oil lines where you want it.

Using readily available stainless steel hose clamps* (not supplied), secure the bracket to the oil lines by placing the clamp through the slot in the bracket and around the lines. Tighten down the clamps.

TIP: We do recommend that you place a small piece of thin sheet rubber (an old tire tube is great, or even a single sided stick on foam tape) between the lines and the bracket to eliminate any possibility to chafing the oil line. This will also make it even more secure.

***: Use the shortest SS clamps possible to eliminate leaving long clamp 'tails'. We recommend using 4 narrow clamps, 2 on each line, but you can use one wide clamp on each side if you prefer. U clamps can also be used, but be sure not to over tighten them and crush the lines.**

And always remember... Never ride faster than your angel can fly!