



4960 SW 29th Way, Ft. Lauderdale, FL 33312
305-345-9444 cycleopsusa@gmail.com

CAUTION!

Handle with care! These are delicate due to the fine detail so do not bend or flex the badges when installing them on the bike or you may crack the chrome finish! It is suggested to first tape them in place with blue masking tape, mark the location, and then peel backing and apply them. You have one shot as this adhesive grabs fast and permanently. To remove use Goo Gone or similar product.

Properly prep the area they are to be applied by using a quality grease and wax remover prior to installation. Install at 70 degrees or more and it is recommended to let them sit overnight to cure.