



**4960 SW 29<sup>th</sup> Way, Ft. Lauderdale, FL 33312**  
**Phone: 305-345-9444**

### **Floorboard Spacer for Talon Exhaust Installation Guide**

Doing one side at a time, remove the floorboard mount to frame bolts. Place the supplied spacer between the mounts and the frame, reinserting the appropriate replacement bolts and torquing them to factory specifications (see your service manual for these specs). It is strongly recommended that you apply an appropriate thread locking agent to the threads prior to installation.

Note: When removing the front bolt on the left side mount it is common for it to 'shift' slightly, don't worry, it's normal. I recommend you have someone sit on the bike, straight up, taking the weight off the kickstand. This eliminates the difficulty in realigning the holes due to the common tendency for the down tube to shift from the weight of the bike leaning over on it. It sometimes requires a second person to help align it to get the bolt in, or simply do it my way... alone with a large punch to align it from behind while I slide the bolt into place.

*All CycleOps USA exhaust products are designed strictly for show and off road use only. Any use other than stated are at the sole discretion of the purchaser. Check your local DOT or Highway Department for laws regarding exhaust system requirements for street use.*