



### **Vision Lower Deflector Installation**

Place the SS spacers on the hinges and then install the deflectors and snug the screws to factory specs.